

Installer Completion Checklist: Wallbeds

Site Preparation

- Ensure the installation area is clean, level, and has enough space for assembly.
- Confirm that all components, hardware, and instructions are present and undamaged.

Wallbed Frame Assembly

Bed Frame Components

- o Confirm all bed frame components are present and free of defects.
- o Assemble the bed frame according to the manufacturer's instructions.
- o Ensure all joints and connections are tightly secured.

Mechanism Installation

- o Confirm that the lift mechanism (springs or pistons) is correctly installed and functioning.
- Attach the mechanism to the bed frame and the wall, following the instructions carefully. Note that the correct number of fixings must be used as per the manual.
- Test the mechanism to ensure smooth operation without excessive force. This should be tested with a mattress in place.

Piston systems

For piston systems, If the bed is too difficult to pull down with a mattress in place, has a hydraulic arm been removed from the left hand side to counterbalance it (they are designed for this purpose).

Spring systems

For spring systems, If the bed is too difficult to pull down with a mattress in place, have the springs been loosened equally on both sides to counterbalance it.

Wall Mounting

Wall Stud Location

- Confirm a stud finder has been used to locate and mark wall studs or suitable fixings points for masonry/brick walls.
- o Confirm that the wallbed is aligned with the studs for secure mounting.

Securing to Wall

- Securely fasten the wallbed frame to the wall using appropriate hardware (coach bolts, screws, etc.).
- o Ensure the bed is level and flush with the wall.
- o Double-check that the bed is securely anchored to prevent tipping.

Surrounding Cabinet (If purchased)

Cabinet Components

o Confirm all cabinet components are present and free from damage.

o Assemble each cabinet according to the manufacturer's instructions.

Cabinet Placement

- o Position the cabinets around the wallbed, ensuring they are level and properly aligned.
- Secure cabinets to the wall, ensuring they are anchored to studs or appropriate support structures. The cabinet must be secured at the fixing points stated in the manual.

Securing Cabinets to Wallbed

Check that all connections are secure and the cabinet is flush with the wallbed.

Mattress Support Installation

- o Install the mattress support slats according to the instructions.
- o Ensure the support is secure and level.

Bed Operation Test

- o Test the operation by raising and lowering the bed several times with the mattress in place.
- o Ensure the bed moves smoothly and stays securely in both the raised and lowered positions.
- o Check that the bed locks into place when upright and does not accidentally open.

Safety Checks

- o Confirm that all screws, bolts, and fasteners are tightly secured.
- o Ensure there are no sharp edges or exposed hardware.
- o Confirm that the bed and cabinet are safely anchored to the wall and floor.

Surface Inspection

- Inspect all surfaces for scratches, dents, or other damage.
- Clean off any dust or debris from the assembly process.

Customer Walkthrough

- o Demonstrate how to properly raise and lower the bed and secure it in place.
- o Invite the customer to operate the wallbed.
- o Review any warranty information and provide the customer with the user manual.

Version 1.0 July 2024